



Powerbox G3

USER MANUAL

Battery Module
51.2V/200Ah

Contents

Statement of Law	1
Revision History	1
Safety Precautions	2
Manual Declaration	4
Safety Statement	4
Sign Explanation	4
1 Introduction	5
Brief Introduction	5
Product Properties	5
Product Identity Definition	6
2 Product Specification	8
Size and Weight	8
Performance Parameter	8
Interface Definition	8
Battery Management System(BMS)	13
3 Installation and Configuration	15
Preparations for Installation	15
Equipment Installation	18
4 Use, Maintenance and Troubleshooting	33
Battery System Usage and Operation Instructions	33
Alarm Description and Processing	34
Analysis and Treatment of Common Faults	35

Statement of Law

Copyright of this document belongs to Dyness Digital Energy Technology Co., LTD.

No part of this documentation maybe excerpted, reproduced, translated, annotated or duplicated in any form or by any means without the prior written permission of Dyness Digital Energy Technology Co., LTD. This product complies with the design requirements of environmental protection and personal safety. The storage, use and disposal of the products shall be carried out in accordance with the product manual, relevant contract or relevant laws and regulations. Customer can check the related information on the website of Dyness Digital Energy Technology Co., LTD. when the product or technology is updated. Please note that the product can be modified without prior notification.

Revision History

Revision NO.	Revision Date	Revision Reason
V0	2026.01.22	First Published
V1.0	2026.07.31	Update the power cable length (1500mm).

Safety Precautions



WARNING

Please do not put the battery into water or fire, in case of explosion or any other situation that might endanger your life.

Please connect wires properly while installation, do not reverse connect.

To avoid short circuit, please do not connect positive and negative poles with conductor on the same device.

Please avoid any form of damage to battery, especially stab, hit, trample or strike.

Please shut off the power completely when removing the device or reconnecting wires during the daily use or it could cause the danger of electric shock.

Please use dry powder extinguisher to put out the flame when encountering a fire hazard, liquid extinguisher could result in the risk of explosion.

For your safety, please do not arbitrarily dismantle any component in any circumstances. The maintenance must be implemented by authorized technical personnel or our company's technical support. Device breakdown due to unauthorized operation will not be covered under warranty.

**CAUTION**

Our product have been strictly inspected before shipment. Please contact us if you find any abnormal phenomena such as device outer case bulging.

The product shall be grounded properly before use In order to ensure your safety.

To assure the proper use please make sure parameters among the relevant device are compatible and matched.

Please do not mixed-use batteries from different manufacturers, different types and models, as well as old and new together.

Ambient and storage method could impact the product life span, please comply with the operation environment instruction to ensure device works in proper condition.

For long-term storage, the battery should be recharged once every 6 months, and the amount of electric charge shall exceed 80% of the rated capacity.

Please charge the battery in 18 hours after it fully discharged or over-discharging protection mode is activated.

Formula of theoretical standby time: $T=C/I$ (T is standby time, C is battery capacity, I is total current of all loads).

The surface of the product cabinet is affixed with a torn invalid label. Therefore, before opening the cover to change the DIP switch mode, you need to contact DYNESS and inform the product ID. DYNESS will record this battery ID and authorize the opening operation to be performed. Except for changing the DIP switch mode, no other operations are allowed. In the next stage, you can log in to apply for operations directly on the DYNESS website. Contact the authorized dealer or distributor of DYNESS for a new torn invalid sticker after tearing the original invalid label. When the operation is completed, paste the new one at a different position.

Preface

Manual Declaration

When you apply the grid or photovoltaic system as your powers supply, the product can collect electricity to charges the battery. When grid or photovoltaic system is power off , the product can supply electricity itself for your home loads.

Powerbox G3 User manual systematically elaborates device structure, parameters, basic procedure and method of installation, operation, maintenance.

Safety Statement

Only qualified trained professionals are allowed to install, operate, maintain the device.

Please comply with local safety regulations and operational rules during installation, operation and maintenance, or it could cause unexpected injury or device damage.

The safety declaration mentioned in the manual are only supplement context for your local safety regulations.

The seller does not undertake any responsibility for device operations or usage of violating general safety requirements and safety standards.

Sign Explanation

User should clear the meaning of the caution sign below when configuring or operating Powerbox G3 series products.



CAUTION

Neglecting the warnings might cause equipment failure.

1 Introduction

Brief Introduction

Powerbox G3 series is equipped with lithium iron phosphate battery for family use . We base on customer needs and market requirement to develop cutting-edge battery storage technology and offer this high quality product to supply stable electricity for all kind of user's devices. The product have long life span and can be applied in high temperature environment and take less space for installation.

Powerbox G3 series carries self-developed battery management system. When you apply the grid or photovoltaic system as your powers supply, the product can collect electricity to charges the battery. When grid or photovoltaic system is power off , the product can supply electricity itself for your home loads.

Products also can be paralleled to build a multi-module system with more capacity to satisfy the longtime energy storage demand.

Product Properties

Powerbox G3 series energy storage product's anode materials are lithium iron phosphate, battery cells are managed effectively by BMS with better performance, the systems features as below:

- Comply with European ROHS, Certified SGS, employ non-toxic, non-pollution environment-friendly battery.
- Anode materials are lithium iron phosphate (LiFePO_4), high safety performance with longer life span.
- Equipped with BMS (battery management system) mode with better performance, possesses protection function like over-discharge, over-charge, over-current, abnormal temperature.
- Self-management on charging and discharging, Single core balancing function.
- Intelligent design configures integrated inspection module.
- Flexible configurations allow parallel of multi battery for longer standby time.
- Less battery self-discharge, then recharging period can be up to 10 months during the storage.
- No memory effect so that battery can be charged and discharged shallowly.

- With wide range of temperature for working environment, $-20^{\circ}\text{C} \sim +55^{\circ}\text{C}$, circulation span and discharging performance are well under high temperature.

Product Identity Definition




Figure 1-1 Battery Energy Storage System nameplate



Figure 1-2 Labels with heating function
 (Only systems with heating function will be labeled)



Figure 1-3 Built-in Aerosol Fire Extinguisher

Table 1-1 Symbol Definition

	Battery voltage is higher than safe voltage, direct contact with electric shock hazard.
	Be careful with your actions and be aware of the dangers.
	Read the user manual before using.
	The scrapped battery cannot be put into the garbage can and must be professionally recycled.
	After the battery life is terminated, the battery can continue to be used after it recycled by the professional recycling organization and do not discard it at will.
	This battery product meets European directive requirements.
	Do not place near open flame or incinerate.
	If catch fire, do not put out with water.
	If catch fire, do not put out with dry powder fire extinguisher.
	Do not cut or spear with sharp objects.

2 Product Specification

Size and Weight

Table 2-1 Powerbox G3 Series Device Model

Product Series	Nominal Voltage	Nominal Capacity	Dimension (mm)	Weight (kg)	IP Level
Powerbox G3	51.2V	200Ah	730×710×165	99.7	IP65


Performance Parameter

Table 2-2 Powerbox G3 performance parameter

Item	Powerbox G3
Nominal Voltage(V)	51.2
Work Voltage Range(V)	44.8~57.6
Nominal Capacity(Ah)	200Ah
Nominal Energy(kWh)	10.24
Recommended Charge/Discharge Current(A)	100
Max Continuous Charging Current(A)	200
Max Continuous Discharging Current(A)	200
Peak Discharging Current(A)	300(2mins,25°C,SOC>20%)

Interface Definition

This section elaborates on interface functions of the front panel of the device.






Figure 2-1 Powerbox G3 the Sketch of Front Interface

Table 2-3 Interface Definition

Item	Name	Definition
1	LED light	Display battery SOC and warning information
2	Reset switch	Press the switch and the battery system turn on. When the battery is in the non-use state such as storage, transportation etc., it needs to be turn off by pressing the Reset switch button, and the battery system will automatically sleep after the device without external load and power for 72 hours
3	Com out	When the system is used independently: This CAN/RS485 socket is a reservation interface When the system is used in parallel: This CAN/RS485 communication socket is connected to the COM IN interface of the next Powerbox G3 through communication cable. (Factory default CAN communication mode)
4	Negative socket	The battery DC output negative pole, which is connected to the negative pole of the inverter through the cable
5	Wifi	Monitoring and optimizing battery systems
6	Ground connection point	Shell ground connection
7	Com in	When the system is used independently: The CAN/RS485 socket is connected to the inverter CAN/RS485 interface through the communication cable. When the system is used in parallel: This CAN/RS485 communication socket is connected to the COM OUT interface of the previous Powerbox G3 through communication cable. (Factory default CAN communication mode)
8	Explosion proof valve	Due to the rapid increase in pressure inside the battery box, the explosion-proof valve exhaust port is opened to quickly and directionally release the

Item	Name	Definition
		internal gas, thereby preventing the battery box from exploding
9	Positive socket	The battery DC output positive pole, which is connected to the positive pole of the inverter through the cable
10	DC circuit breaker	Circuit protection
11	DIP	Master communication baud rate selection

Table 2-4 LED Status Indicators

LED status	Information
	SOC 50%
	SOC 100%
Current SOC increases to 100% ,then cycles 	Charge
Drop from current SOC to 0%, then loop 	Discharge
Green light flashing(Current SOC) 	Standby
Yellow light flashing 	Communication failure between batteries or communication failure between lamp board and BMS
Red light on 	System protection

Battery Management System(BMS)

Voltage Protection

Low Voltage Protection in Discharging:

When any battery cell voltage or total voltage is lower than the rated protection value during discharging, the over-discharging protection is activated, the “D” light will remain constantly lit in red, and the battery buzzer makes an alarm sound. Then battery system stops supplying power to the outside. When the voltage of each cell back to rated return range, the protection is over.

Over Voltage Protection in Charging:

During charging stage, the system will stop charging when the total voltage of the battery pack is higher than rated value or the voltage of any single cell reaches the protection value. When total voltage or all cell back to rated range, the protection is over.

Current Protection

Over Current Protection in Charging:

When the charge current of any module $> 210A$, current limit protection mode is activated, current will be limited to $\leq 3A$, protection is removed after rated time delaying 10s. Circulate like this until the current is lower than 210A.

Over Current Protection in Discharging:

When the discharge current of any module is higher than 305A, the “D” light will remain constantly lit in red, the battery buzzer alarms and the system stops discharging at once. After protection, the discharging will restore in 60secs delay or immediately when there is charging current.



CAUTION

The buzzer sound alarm setting can be manually turned off on the background software, and the factory default is on.

Temperature Protection

Low/Over temperature protection in charging:

When battery's temperature is beyond range of 0°C~+55°C during charging, temperature protection be activated, device stops charging.

The protection is released when it back to rated range of working temperature.



CAUTION

If you choose a product with heating function the charging temperature range is -20°C~+55°C.

Low/Over temperature protection in discharging:

When battery's temperature is beyond range of -20°C ~+55°C during discharging, temperature protection is activated, device stops supplying power to the outside.

The protection is over when temperature back to rated working range.

Other Protection

Short Circuit Protection:

When the battery is activated from the shutdown state, if a short circuit occurs, the system starts short-circuit protection for 60 seconds.

Self Shutdown:

When device connects no external loads and power supply and no external communication for over 72 hours, device will dormant standby automatically.



CAUTION

The maximum operating current required for the electrical load shall be less than the maximum discharge current capacity of the battery.

3 Installation and Configuration

Preparations for Installation

Safety Requirement

This system can only be installed by personnel who have been trained in the power-supply system and have sufficient knowledge of the power system. The safety regulations and local safety regulations listed below should always be followed during the installation.

- All circuits connected to this power system with an external voltage of less than 48V must meet the SELV requirements defined in the IEC60950 standard.
- If operating within the power system cabinet, make sure the power system is not charged. Battery devices should also be switched off
- Distribution cable wiring should be reasonable and has the protective measures to avoid touching these cables while operating power equipment.
- The following protective items must be worn when installing the battery system:



Insulated Gloves



Safety Goggles



Safety Shoes

Figure 3-1 Safety Gear

Environmental requirements

Working temperature: $-20^{\circ}\text{C}\sim+55^{\circ}\text{C}$.

Charging temperature range is $0^{\circ}\text{C}\sim+55^{\circ}\text{C}$.

Note: When selecting a heating film, the charging temperature range is $-20^{\circ}\text{C}\sim+55^{\circ}\text{C}$.

Discharging temperature range is $-20^{\circ}\text{C}\sim+55^{\circ}\text{C}$.

Storage temperature: $-10^{\circ}\text{C}\sim+35^{\circ}\text{C}$.

Relative humidity: 5% ~ 85%RH.

Elevation: no more than 4000m .

Operating environment: Indoor or outdoor installation, sites avoid the sunlight and no wind, no conductive dust and corrosive gas.

And the following conditions are met:

- Installation location should be away from the sea to avoid brine and high humidity environment.
- The ground for product arrangement shall be flat and level.
- There is no flammable explosive materials near to the installation site.
- The optimal ambient temperature is 15°C~30°C.
- Keep away from dust and messy zones.

Tools and data

Tools and meters that may be used are shown in Figure 3-2 Installation Tools.



Figure 3-2 Installation Tools

Technical Preparation

Electrical interface check

Devices that can be connected directly to the battery can be user equipment, power supplies, or other power supplies.

- Confirm whether the user equipment, the PV equipment or other power supply equipment has the DC output interface, and measure whether the output voltage of the standby interface meets the requirements of the voltage range of table 2-2.
- Verify that the maximum discharge current capacity of the user equipment, the PV equipment or other power supplies, the DC standby interface, and the maximum discharge current shall be greater than the maximum charging current of the products used in table 2-2.
- If the user equipment DC prepared interface maximum discharge capacity is less than the maximum charging current products using table 2-2, the user

interface should have the power equipment of DC current limiting function, give priority to ensuring the normal work of user equipment.




The security check




- Firefighting equipment should be arranged near the equipment, such as portable dry powder fire extinguisher.
- Automatic fire fighting system shall be provided for the case where necessary.
- Flammable, explosive and other dangerous materials placed beside the battery are prohibited.

Unpacking Inspection

- When the equipment arrives at the installation site, loading and unloading should be carried out according to the rules and regulations, so as to prevent from being exposed to sun and rain.
- Before unpacking, the total number of packages shall be indicated according to the shipping list attached to each package, and the case shall be checked for good condition.
- In the process of unpacking, handle with care and protect the surface coating of the object.
- Open the package, the professional installation personnel should read the technical documents, verify the list, according to the configuration table and packing list, ensure objects are complete and intact. If the internal packaging is damaged, it must be inspected and recorded in detail.

Table 3-1 Packing list

Item	Specification	Quantity	Figure
Battery	Powerbox G3 51.2V/200Ah	1	
Wall bracket	Wall bracket	1	
Fixing bracket	/	1	

Unlock Piece-BLACK	/	1	
Positioning cardboard	/	1	
Quick Installation Manual	Quick Installation Manual	1	
Cross Recessed Pan Head three combination Screw	M6	1	
Step screws	M8	6	
Hexagon Head Tapping Screw	M6	4	
OT terminal	OT 4-6	2	
CAN resistor	/	1	
Communication parallel cable	Black /L2000mm /Double RJ45 plug	1	
Communication cable to inverter	Black /L2000mm /Double RJ45 plug	1	
Power cable-positive	Red /1AWG/L 1500mm	1	
Power cable-negative	Black /1AWG/L 1500mm	1	

Letter to customer	/	1	
Warranty card	/	1	
Packing list	/	1	


Engineering Coordination

Attention should be paid to the following items before construction:

- Power cable specification.
- The power cable specification shall meet the requirements of maximum discharge current for each product.
- Mounting space and bearing capacity.
- Make sure that the battery has enough space to install, and that the battery rack and bracket have enough load capacity.
- Wiring.
- Make sure the power cable and ground wire are reasonable. Not easy to short-circuit, water and corrosion.

Equipment Installation

The wall for battery installation shall be solid brick or cement wall with strong bearing capacity and wall thickness no less than 100mm.



Floor installation

Wall installation

Figure 3-3 Mounting Space Requirements



*Recommended installation distance: >500mm

Table 3-2 Installation Steps


Step 1 System preparation
Ensure that the battery is in a shutdown state
Step 2 Mechanical installation
1. Hanger mounting
2. Equipment installation
Step 3 Electrical installation
1. Connect the ground cable
2. Electrical installation
3. Connect inverter
Communication interface connection

Wall hanging Installation method:


The following accessories need to be added when install the Powerbox G3 on the wall.

	
Wall bracket ×1	Hexagon Head Tapping Screw ×4
	
Step screws ×6	


1. Use the wall bracket (provided in accessory package) and mark the screw hole positions on the wall.
2. The bracket must be perpendicular to the ground while drawing the holes.
3. The bottom of the bracket is about 385mm from the ground.
4. According to the position of the mark, 4 holes in diameter 10mm and depth of more than 80mm are hit on the wall with an electric drill, which are used for fitting Hexagon Head Tapping Screw M6.




5. Fix the wall bracket on the wall with M6 Hexagon Head Tapping Screw, twisting force keeps $9.8\text{N}\cdot\text{m}$.



6. As shown in the figure below, lock two M8 step screws to the battery module. Twisting force keeps $11.8\text{N}\cdot\text{m}$.





7. When Powerbox G3 battery wall hanging installing, pay attention to insert the two screw heads on the back of the chassis into the slot on the wall hanging ((The Powerbox G3 weighs approximately 100 kg. When handling and installing it, it is recommended that more than two engineers operate it, or operate it with the help of the distributor's professional tools)).




Floor installation method:

When installing the Powerbox G3 on the ground, the following accessories are required.

		
Fixing bracket ×1	Cross Recessed Pan Head three combination Screw ×1	Hexagon Head Tapping Screw ×1

1. Secure the hanging ear on the left or right side of the battery.
2. Mark the drilling positions on the wall.
3. According to the position of the mark, 1 holes in diameter 10mm and depth of more than 80mm are hit on the wall with an electric drill, which are used for fitting expansion bolt M6.



Electrical installation

Before connecting the power cables, using multimeter to measure cable continuity, short circuit, confirm positive and negative, and accurately mark the cable labels.

Measuring method:

Power cable check: Select the buzzer mode of multimeter and detect the both ends of the same color cable. If the buzzer calls, it means the cable is in good condition.

Short circuit judgment: Choose multimeter resistor file, probe the same end of positive and negative pole, if the resistor shows infinity, means that the cable is available.

After visual testing of power line is connection, the positive and negative poles of the battery shall be connected respectively to the positive and negative poles of the opposite terminal.

The customer shall prepare a grounding cable to ground the battery as shown below. The cross-sectional area of the grounding cable shall be at least 6mm², and the bolt tightening torque shall be 6 N·m.




Figure 3-4 Battery Grounding Diagram



CAUTION

If there is any question during installation, please contact your dealer to avoid damage to the equipment.

Inverter Connection

When the system is used independently:

Note: Before installation, please confirm whether the DIP switch mode of the Powerbox G3 is correct according to use's inverter communication specification. For specific DIP operation methods, please refer to "P29 Battery module DIP switch definition and description".

The battery is connected to the inverter, and it is required to use the dedicated power cable and communication cable (as accessories shipped with the cargo, the standard communication cable is a standard network cable. The applicable inverter is marked on the label of the network cable. If the inverter used by the customer is not covered by the standard communication cable, please contact DYNES for the correct PIN Sequence) as follows:

Keep the battery system at power off state, connect the power cable to the interface on the input side of the inverter first, and then connect the power cable to the interface on the battery side.

The battery output interface is a waterproof connector, and the power cord (positive and negative) plug needs to be locked into the battery socket. The cable model is 1AWG cable.

Note: Connect the communication interface. Use the dedicated RJ45 cable in the accessory package to connect the CAN IN port of the battery to the CAN or RS485 communication interface of the inverter.




Figure 3-5 Schematic Diagram of Cable Connection

The installation method of waterproof RJ45 cables is as shown in the figure below:




Figure 3-6 Installation Diagram of Waterproof RJ45 Cable Plug

Table 3-3 Pin Definition(CAN IN)

Foot position	Color	Definition
PIN1	Orange/white	485B
PIN2	Orange	485A
PIN3	Green/white	Reserve
PIN4	Blue	EXT CANH
PIN5	Blue/white	EXT CANL
PIN6	Green	Reserve
PIN7	Brown/white	INT CANH
PIN8	Brown	INT CANL

(CAN OUT)

Foot position	Color	Definition
PIN1	Orange/white	Reserve
PIN2	Orange	Reserve
PIN3	Green/white	Reserve
PIN4	Blue	Reserve
PIN5	Blue/white	Reserve
PIN6	Green	Reserve
PIN7	Brown/white	INT CANH
PIN8	Brown	INT CANL




Figure 3-7 Schematic Diagram of Independent System Usage

When the system used in parallel:


When multiple Powerbox G3 units are running simultaneously in the system, please strictly follow the following requirements for use (to avoid hazards caused by improper operation).

When the power of the inverter system $\leq 10\text{kW}$:

1. Batteries are connected using parallel cables (special parallel cables need to be ordered separately);
2. The system's main positive cable is installed on the first Powerbox G3, and the system's main negative cable is installed on the last Powerbox G3 (the cables are in the accessory package);
3. Batteries communicate using parallel network cables, and the main battery communicates with the inverter using external network cables (the network cables are in the accessory package);


4. The system supports up to 50 Powerbox G3 units operating in parallel.

When the batteries are connected in parallel, the host communicates with the slaves through the CAN interface. The host summarizes the information of the entire battery system and communicates with the inverter through CAN or 485. If the master is the latest battery with DIP switch, For different inverter model, you need to set different DIP mode.




10kW < When the power of the inverter system ≤ 20 kW:

1. The inverter must support the simultaneous connection of two pairs of cables larger than 50 square meters;
2. Batteries are connected using parallel cables (special parallel cables need to be ordered separately);
3. Both the first Powerbox G3 and the last Powerbox G3 within the system need to be externally connected to a pair of cables (the cables are in the accessory kit);
4. Batteries communicate using parallel network cables, and the main battery communicates with the inverter using external network cables (the network cables are in the accessory package);
5. The system supports up to 50 Powerbox G3 units operating in parallel (when two Powerbox G3 units are used in parallel, there is no need to connect a parallel cable between the batteries).



20kW<When the power of the inverter system:

1. A combiner box must be used for confluence (available for purchase from Dyness);
2. All Powerbox G3 units must be connected to the combiner box via cables (the cables are in the accessory package);
3. Batteries communicate using parallel network cables, and the main battery communicates with the inverter using external network cables (the network cables are in the accessory package);
4. The system supports up to 50 Powerbox G3 units operating in parallel.



Note: The parallel network cable between battery packs and the parallel network cable between batteries and inverters have different functions and must not be used interchangeably !

Note: When multiple batteries are used in parallel, simply set the DIP switch of the main battery to the corresponding DIP mode, and the slave batteries do not need to have their DIP switches set.

The host communicates with the slaves through the CAN interface. The host summarizes the information of the entire battery system and communicates with the inverter through CAN or 485. If the master is the latest battery with DIP switch, For different inverter model, you need to set different DIP mode.

Please refer to Table 3-4 DIP Switch Description.

Battery Module DIP Switch Definition and Description


Table 3-4 DIP switch Definition

DIP switch position (master communication protocol and baud rate selection)			
#1	#2	#3	#4
Define different protocols; Distinguish between master and slave			Baud rate selection
			OFF: CAN: 500K,485: 9600
			ON: CAN: 250K,485: 115200


Table 3-5 DIP Switch Description

DIP Switch Description
1. If the battery communicates with inverters such as Solis、GOODWE、TBB、SAJ、SOLAX, before starting the battery, you don't to change the DIP. Maintain factory mode 0000. ON DIP 1 2 3 4 Default setting
2. If the battery communicates with inverters such as SMA、Victron、Ingeteam、Solplanet、SOFAR、Deye、Hoymiles、APsystems、LUXPOWER、MUST、SOSEN、Afore、Solis、GOODWE、TBB、SAJ、SOLAX, please turn the master DIP switch "#3" to "ON" position. ON DIP 1 2 3 4 → ON DIP 1 2 3 4 Master setting 1
3. If the battery communicates with inverters such as Apxert-king/VMIII/MAX、Infinisolar、Growatt SPH/SPA(CAN com), please turn the master DIP switch "#2" to "ON" position. ON DIP 1 2 3 4 → ON DIP 1 2 3 4 Master setting 2

4. If the battery communicates with inverters such as Growatt SPF HVM-P/ES/ WPV by RS485 communication, please turn the master DIP switch "#2" and "#3" to "ON".



5. If the battery communicates with inverters such as Schneider Conext Series, please turn the master DIP switch "#1" and "#3" to "ON".



6. When you setup the master DIP as setting 1~4, all the slaves keep the DIP 0000, no need to change.

7. If the energy storage system has only one Powerbox G3, it is the master itself, and still follow the above steps.

Note: For more information of matching inverter brands, please subject to the latest document<The list of compatibility between Dyness ESS and Inverters >.




CAUTION

- If the battery communicates with inverters such as Goodwe, Solis, VICTRON,TBB, SAJ(CAN Comm), SOLAX before starting the battery, You can choose not to replace the DIP switch.Maintain factory mode 0000.



CAUTION

- When the number of parallel machines exceeds 12, CAN resistance needs to be added to the CAN OUT interface of the last battery.Refer to the following diagram.



**CAUTION**

- Before connection, the positive and negative pole of the inverter input interface and the battery output interface should be confirmed.
- The red power line is connected to the positive pole and the black power line is connected to the negative pole.
- Before connection, it is necessary to confirm the charge and discharge parameters of the inverter interface.
- Voltage and current should meet the requirements of Table 2-2 battery performance parameters.
- Note: For more information of matching inverter brands, please subject to the latest document <The list of compatibility between Dyness ESS and Inverters >.
- The following operations can only be performed after being authorized by DYNESS:
 - How to judge that the communication between the product is normal:
 1. If there is communication between the inverter and battery system, it can be judged by the maximum charge and discharge current value on the inverter sent by the battery.
(The maximum charge and discharge current value display on the inverter)/(The maximum charge and discharge current value of one battery module)=number of modules
 - 2.If the equation holds after calculation, it means communication between the Powerbox G3 is normal.
 - 3.If the master battery LED flashes yellow, it means the communication between Powerbox G3 is fault.

Table 3-6 Battery usage recommendations

Equipment Use	Charging	1.The battery's long-term continuous charging current should be $\leq 1C$. 2.If the battery remaining capacity is empty, please charge it within 48 hours after the battery is empty.
---------------	----------	---

- Discharging
- 3.The long-term continuous discharge current of the battery should be $\leq 1C$.
 - 4.The recommend maximum depth of discharge (DOD) of Battery PACK is no more than 95%.

Table 3-7 Battery & Inverter Power Matching Table

Power of Hybrid Inverter/Off-grid Inverter	Powerbox G3 Type	System Energy(kWh)
5KW	1*Powerbox G3	10.24
10KW	1~2*Powerbox G3	10.24~20.48
15KW	2~3*Powerbox G3	20.48~30.72

Battery Parameter Settings on the Inverter

Max Charging(Bulk) Voltage: 57.6V

Absorption Voltage: 56.5V

Float Voltage: 56V

Shut Down(cut off) Voltage: 48V

Shut Down(cut off) SOC: 5%

Restart Voltage: 52V

Max Continuous Charging Current:200A


Max Continuous Discharging Current: 200A

4 Use, Maintenance and Troubleshooting

Battery System Usage and Operation Instructions

After completing the electrical installation, follow the instruction below to start the battery system.

1. Push the air switch to the "ON" position, and remember to tighten the nuts on the breaker cover.



2. Press the battery power button. After the self-inspection is completed, the "D" logo on the front panel of the chassis shows the green light flashing, and the battery enters the standby state.



CAUTION

- After pressing the wake/sleep button, If the battery status indicator is steady red or blinking yellow, please refer to the "Alarm description and processing". If the failure cannot be eliminated, please contact the retailer timely.

1. Use a voltmeter to measure whether the voltage across the BAT + / BAT- terminals of the inverter is higher than 44.8V, and check whether the voltage polarity is consistent with the input polarity of the inverter. If the voltage across the terminals BAT + / BAT- of the inverter is higher than 44.8V, which means the battery has begun to work normally.
2. After confirm the battery output voltage and polarity are correct, turn on the inverter.
3. Check whether the indicator light for the inverter and the battery connection (the communication indicator and the battery access status indicator) is in normal condition. If normal, the connection between the battery and the inverter is completed. If the indicator light show abnormal, please check the inverter manual or contact the local dealer.

Alarm Description and Processing

When protection mode is activated or system failure occurred, the LED indicator on the front panel will alarm, through net management can query specific alarm class and take appropriate action.

Alarm and countermeasure for affecting system output

If there are any abnormalities affecting the output, such as battery cell in the battery module occurs over-current protection during charge/discharge, under-voltage protection, and temperature protection, in the system, please deal with them according to Table 4-1.

Table 4-1 Main Protection

Statue	Alarm category	Alarm indication	Processing
Charge state	Over-current protection when charge	RED light Always on Buzzer start	Stop charging and reduce charge current below rated value
	High temp protection when charge	RED light Always on	Stop charging and find out the cause of the trouble
Discharge state	Over-current protection when discharge	RED light Always on Buzzer start	Stop discharging and reduce discharge current below rated value
	High temp protection when discharge	RED light Always on	Stop discharging and find out the cause of the trouble
	Over-discharged protection	RED light Always on Buzzer start	Start charging

Analysis and Treatment of Common Faults

Table 4-2 Analysis and Treatment of Common Faults

Item	Fault phenomenon	Reason analysis	Solution
1	The indicator does not respond after power on the system	Make sure press and hold the power switch (Reset switch) for 3s	Check the total voltage
2	No DC output after power on the system	Check if the DC breaker is turned on	Check the status of the DC circuit breaker on the side of cabinet
3	No DC output and red light is ON, buzzer beeping	Battery voltage is too low	Charging the battery system
4	The battery cannot be fully charged	Charging voltage is too low	Adjust charging voltage within 57.1V~57.6V range
5	The power cable sparks once power on and ALM indicated Red light on	Power connection short-circuit	Turn off the battery, check the cause of the short circuit
6	Master battery yellow light flashing	Abnormal communication between batteries	Check if the communication network cable connection between the batteries is correct
7	Battery yellow light flashing	Abnormal communication between battery motherboard and light board	Contact the dealer's after-sales engineer

If you need any technical help or have any question, please contact the dealer in time.



Address: Building 1&2, 7th–8th Floors, Building 3, No. 58 Nanhu Road, Chengnan Subdistrict,
Wuzhong District, Suzhou City, Jiangsu Province
Email: service@dyness-tech.com
Tel: +86 400 666 0655
Web: www.dyness.com



Official Website